

DERAS WEBSOCKET PROTOCOL V1.5

Sebelum menggunakan Websocket protokol pastikan aplikasi DERAS.EXE sudah berjalan dan terkoneksi dengan Hardware.

WEBSOCKET PROTOCOL:

URL: localhost:3030

- **Get RFID Power**
 - **Payload:**
{event: "get-rfid-power" }
 - **Success Response:**
{ "event": "response-get-rfid-power", "statusCode": 1, "message": "success!", "value": 20 }
 - **Error Response:**
{ "event": "response-get-rfid-power", "statusCode": 0, "message": "failed!" }

- **Set RFID Power**
 - **Payload:**
{event: "set-rfid-power", "value": 30 }
 - **Success Response:**
{ "event": "set-rfid-power", "statusCode": 1, "message": "success!" }
 - **Error Response:**
{ "event": "set-rfid-power", "statusCode": 0, "message": "failed!" }

- **Set Buzzer on**
 - **Payload:**
{event: "set-buzzer-on" }
 - **Success Response:**
{ "event": "response-set-buzzer-on", "statusCode": 1, "message": "success: set-buzzer-on" }
 - **Error Response:**
{ "event": "response-set-buzzer-on", "statusCode": 0, "message": "failed: set-buzzer-on" }

- **Set Buzzer off**
 - **Payload:**
{event: "set-buzzer-off" }
 - **Success Response:**
{ "event": "response-set-buzzer-off", "statusCode": 1, "message": "success: set-buzzer-off" }
 - **Error Response:**
{ "event": "response-set-buzzer-off", "statusCode": 0, "message": "failed: set-buzzer-off" }

- **Scan RFID On**
 - **Payload:**
{ "event": "scan-rfid-on" }
 - **Success Response:**
{ "event": "response-scan-rfid-on", "statusCode": 1, "message": "success!" }
 - **Error Response:**
{ "event": "response-scan-rfid-on", "statusCode": 0, "message": "error ____" }

**setelah event "scan-rfid-on" dikirim ke server localhost:3030, maka UHF RFID akan merespon dengan melempar data yang dibacakan dengan format "scan-rfid-event".*

- **Scan RFID Off**
 - **Payload:**
{event: "scan-rfid-off"}
 - **Success Response:**
{event: "response-scan-rfid-off", statusCode: 1, message: "success!"}
 - **Error Response:**
{event: "response-scan-rfid-off", statusCode: 0, message: "error ____"}

- **Scan RFID Single**
 - **Payload:**
{event: "scan-rfid-single"}
 - **Success Response:**
{event: "response-scan-rfid-single", statusCode: 1, message: "success!"}
 - **Error Response:**
{event: "response-scan-rfid-single", statusCode: 0, message: "error ____"}

- **Scan Pick To Light**
 - **Payload:**
{ "event" : "scan-rfid-light-on", "value": { "tid": "E281D0152000F7196907C13C"}}
 - **Success Response:**
{ "event": "response-scan-rfid-light-on", "statusCode": 1, "message": "success!"}
 - **Error Response:**
{ "event": "response-scan-rfid-light-on", "statusCode": 0, "message": "Error Scan / Not Found" }

- **Scan RFID Event**
 - **Response:**
{ "event": "scan-rfid-result", "type": 1, "data": "739015CFEEF95761629C9D9A72992EC8", "data_tid": "E28011702000141C5890A71", "pc": null, "user": "", "ant": "1", "rssi": "-60.7", "sensor": null, "rfid_valid": "1" }

- **Set GPIO pin 3-4 (Turn-on)**
 - **Payload:**
{ "event" : "set-gpio-on" }
 - **Success Response:**
{ "event": "response-set-gpio-on", "statusCode": 1, "message": "succes: set-gpio-on" }
 - **Error Response:**
{ "event": "response-set-gpio-on", "statusCode": 0, "message": "error: set-gpio-on" }

- **Ser GPIO pin 3-4 (Turn-off)**
 - **Payload:**
{ "event" : "set-gpio-off" }
 - **Success Response:**
{ "event": "response-set-gpio-on", "statusCode": 1, "message": "succes: set-gpio-off" }
 - **Error Response:**
{ "event": "response-set-gpio-on", "statusCode": 0, "message": "error: set-gpio-off" }

DATABASE ACCESS:

- **[READ] Get List Tags**
 - **Payload:**
{ "event": "db-storage-get-rfid-list" }
 - **Success Response:**
{ "event": "response-db-storage-get-tags", "statusCode": 1, "message": "success", "value": [{"id": 0, "tid": "E2801170200012EEE06C0B4BFD9001220D0A", "status": 1}, { ... }, { ... }] }
 - **Error Response:**
{ "event": "response-db-storage-get-tags", "statusCode": 0, "message": "error: Data not found!" }

- **[CREATE] Insert Tags**
 - **Payload:**

```
{
  "event" : "db-storage-insert-rfid-list",
  "value": {
    "tid": "1234567890ABCDEF",
    "epc": "E2000017221101441890B3D4",
    "status": 1,
    "category": 2,
    "description": "Sample RFID tag description",
    "flag_alarm": 0,
    "created_time": "2023-10-10T14:48:00Z",
    "alias_antenna": "Antenna1",
    "no_sku": "SKU12345"
  }
}
```
 - **Success Response:**

```
{"event":"response-db-storage-insert-rfid-list","statusCode":1,"message":"success"}
```
 - **Error Response:**

```
{"event": "response-db-storage-insert-rfid-list", "statusCode": 0, "message": "error: insert data!" }
```

- **[UPDATE] Update Tags**
 - **Payload:**

```
{
  "event" : "db-storage-update-rfid-list",
  "value": {
    "tid": "1234567890ABCDEF",
    "epc": "E2000017221101441890B3D4",
    "status": 1,
    "category": 2,
    "description": "Sample RFID tag description",
    "flag_alarm": 0,
    "created_time": "2023-10-10T14:48:00Z",
    "alias_antenna": "Antenna1",
    "no_sku": "SKU12345"
  }
}
```
 - **Success Response:**

```
{"event":"response-db-storage-update-rfid-list","statusCode":1,"message":"success"}
```
 - **Error Response:**

```
{"event":"response-db-storage-update-rfid-list","statusCode":0,"message":"error: update data!"}
```

- **[DELETE] Remove Tags**
 - **Payload:**

```
{
  "event" : "db-storage-remove-rfid-list",
  "value": { "tid": "E280..." }
}
```
 - **Success Response:**

```
{"event":"response-db-storage-remove-rfid-list","statusCode":1,"message":"success"}
```
 - **Error Response:**

```
{"event":"response-db-storage-remove-rfid-list","statusCode":0,"message":"error remove data!"}
```

DATABASE REPORT LOGS AND ALIAS ZONA:

- **GET ALIAS ZONA:**
 - **Payload:**

```
{
  "event" : "local-get-alias-antenna"
}
```
 - **Success Response:**

```
{
  "event": "response-local-alias-antenna",
  "statusCode": 1,
  "message": "success",
  "value": [
    {"ant": 1, "alias": "WAREHOUSE1"},
    {"ant": 2, "alias": "WAREHOUSE2"},
    {"ant": 3, "alias": "WAREHOUSE3"},
    {"ant": 4, "alias": "WAREHOUSE4"}
  ]
}
```
 - **Error Response:**

```
{
  "event": "response-local-alias-antenna",
  "statusCode": 0,
  "message": "error get data!"
}
```

- **GET LOG REPORT HISTORY**

- **Payload:**

```
{ "event": "report-logs" }
```

- **Success Response:**

```
{ "event": "response-report-logs", "statusCode": 1, "message": "success", "value": [{"id": 0, "tid": "E280689420004025A81158A5", "epc": "E280689400004025A81158A5", "status": 1, "created_time": "2024-11-01T16:25:15.7070625", "description": "LAUNDRY TAG", "category": 0, "flag_alarm": 0, "ant": 0, "alias_antenna": "WAREHOUSE1", "no_sku": "-"}, {"id": 0, "tid": "E280689420004025A81158A5", "epc": "E280689400004025A81158A5", "status": 1, "created_time": "2024-11-01T16:24:11.2968277", "description": "LAUNDRY TAG", "category": 0, "flag_alarm": 0, "ant": 0, "alias_antenna": "WAREHOUSE1", "no_sku": "-"}]}
```

- **Error Response:**

```
{ "event": "response-report-logs", "statusCode": 0, "message": "error get data!" }
```

- **Payload params conditions:**

** you can also use conditions to find some specific data as you need, the conditions params are nullable.
example:*

```
{  
  event: "report-logs",  
  value: {  
    conditions: {  
      start_date: "....",  
      end_date: ".....",  
      alias_antena : "....",  
      description: "....",  
      tid: "..."  
    }  
  }  
}
```

- **GET LISTENER TUDI LACAK REAL-TIME:**

- **Listener event:**

```
{  
  "event": "response-db-storage-rfid-list-check",  
  "status": 1,  
  "message": "success",  
  "data": {  
    "tid": "1234567890ABCDEF",  
    "epc": "E2000017221101441890B3D4",  
    "status": 1,  
    "category": 2,  
    "description": "Sample RFID tag description",  
    "flag_alarm": 0,  
    "created_time": "2023-10-10T14:48:00Z",  
    "alias_antenna": "Antenna1",  
    "no_sku": "SKU12345"  
  }  
}
```

Example using websocket plugin chrome browser

URL
ws://localhost:3030 Close
Status: **OPENED**

Request

```
{ "event": "scan-rfid-off" }
```

Send (Ctrl + Enter)

Message Log Clear

```
{ "event": "scan-rfid-on" }
{"event": "response-scan-rfid-on", "statusCode": 1, "message": "success!"}
{"event": "scan-rfid-result", "type": 1, "data": {"739015CFEEF95761629C9D9A72992EC8", "data_tid": "E280117020000141C5890A71", "pc": null, "user": "", "ant": "1", "rssi": "-60.7", "sensor": null, "rfid_valid": "0", "message": null}}
{"event": "scan-rfid-result", "type": 1, "data": {"E2801170000021A08996088", "pc": null, "user": "", "ant": "1", "rssi": "-68.0", "sensor": null, "rfid_valid": "0", "message": null}}
{"event": "scan-rfid-result", "type": 1, "data": {"E2806995000040037351D0E8", "pc": null, "user": "", "ant": "1", "rssi": "-45.7", "sensor": null, "rfid_valid": "0", "message": null}}
{"event": "scan-rfid-result", "type": 1, "data": {"AA6474483CA9DB92849F0D0E8E3FCDF1", "data_tid": "E280117020000168C2020849", "pc": null, "user": "", "ant": "1", "rssi": "-73.5", "sensor": null, "rfid_valid": "0", "message": null}}
{"event": "scan-rfid-result", "type": 1, "data": {"E2801170000021A08996088", "pc": null, "user": "", "ant": "1", "rssi": "-68.0", "sensor": null, "rfid_valid": "0", "message": null}}
{"event": "scan-rfid-result", "type": 1, "data": {"AA6474483CA9DB92849F0D0E8E3FCDF1", "data_tid": "E280117020000168C2020849", "pc": null, "user": "", "ant": "1", "rssi": "-73.8", "sensor": null, "rfid_valid": "0", "message": null}}
{"event": "scan-rfid-result", "type": 1, "data": {"E2806995000040037351D0E8", "pc": null, "user": "", "ant": "1", "rssi": "-45.2", "sensor": null, "rfid_valid": "0", "message": null}}
{"event": "scan-rfid-result", "type": 1, "data": {"739015CFEEF95761629C9D9A72992EC8", "data_tid": "E280117020000141C5890A71", "pc": null, "user": "", "ant": "1", "rssi": "-60.9", "sensor": null, "rfid_valid": "0", "message": null}}
{"event": "scan-rfid-result", "type": 1, "data": {"E2801170000021A08996088", "pc": null, "user": "", "ant": "1", "rssi": "-75.7", "sensor": null, "rfid_valid": "0", "message": null}}
{"event": "scan-rfid-result", "type": 1, "data": {"739015CFEEF95761629C9D9A72992EC8", "data_tid": "E280117020000141C5890A71", "pc": null, "user": "", "ant": "1", "rssi": "-61.4", "sensor": null, "rfid_valid": "0", "message": null}}
{"event": "scan-rfid-result", "type": 1, "data": {"E2801170000021A08996088", "pc": null, "user": "", "ant": "1", "rssi": "-77.1", "sensor": null, "rfid_valid": "0", "message": null}}
{"event": "scan-rfid-result", "type": 1, "data": {"E2806995000040037351D0E8", "pc": null, "user": "", "ant": "1", "rssi": "-46.3", "sensor": null, "rfid_valid": "0", "message": null}}
```

Example C#:



```
// Run DERAS.EXE first! before connect via websocket client!
using WebSocketSharp;
using System;

class Program
{
    static void Main(string[] args)
    {
        using (var ws = new WebSocket("ws://localhost:3030"))
        {
            // Event handler for receiving messages from the server
            ws.OnMessage += (sender, e) =>
            {
                Console.WriteLine("Received from server: " + e.Data);
            };

            ws.Connect();
            string message = "{\"event\": \"scan-rfid-on\"}";
            ws.Send(message);
            Console.WriteLine("Message sent: " + message);

            // Wait for a response from the server
            Console.ReadLine();
            ws.Close();
        }
    }
}
```

Example Python:

```
import asyncio
import websockets

async def send_message():
    uri = "ws://localhost:3030"
    async with websockets.connect(uri) as websocket:
        message = '{"event": "scan-rfid-on"}'
        await websocket.send(message)
        print(f"Sent: {message}")

        # Receiving response from the server
        response = await websocket.recv()
        print(f"Received from server: {response}")

asyncio.get_event_loop().run_until_complete(send_message())
```

Example Javascript:

```
const ws = new WebSocket("ws://localhost:3030");

ws.onopen = function() {
  const message = '{"event": "scan-rfid-on"}';
  ws.send(message);
  console.log("Message sent: " + message);
};

// Event listener for receiving messages from the server
ws.onmessage = function(event) {
  console.log("Received from server: " + event.data);
};

ws.onclose = function() {
  console.log("Connection closed");
};
```

Example PHP:

```

<?php
require __DIR__ . '/vendor/autoload.php';

\Ratchet\Client\connect('ws://localhost:3030')->then(function($conn) {
    $message = '{"event": "scan-rfid-on"}';
    $conn->send($message);
    echo "Message sent: " . $message . "\n";

    // Handling the response from the server
    $conn->on('message', function($msg) use ($conn) {
        echo "Received from server: {$msg}\n";
        $conn->close();
    });
}, function ($e) {
    echo "Could not connect: {$e->getMessage()}\n";
});
?>
```